

# Liebert® Air Cooled, Direct Drive Condensers

User Manual - 50/60Hz





---

# TABLE OF CONTENTS

<b>1.0</b>	<b>INTRODUCTION</b> .....	<b>1</b>
1.1	Product Description and Features .....	1
1.2	Head Pressure Control Types .....	2
1.2.1	Fan Speed .....	2
1.2.2	Variable Frequency Drive .....	2
1.2.3	Liebert Lee-Temp™ Refrigerant Control .....	3
1.3	Sound Level Options .....	3
1.3.1	Standard Condenser .....	3
1.3.2	Liebert Quiet-Line Condenser .....	3
1.4	Surge Protection Device .....	3
1.5	Typical System Configurations .....	3
<b>2.0</b>	<b>SITE PREPARATION</b> .....	<b>5</b>
2.1	Site Considerations .....	5
2.2	Dimensions and Weights .....	5
2.3	Refrigerant Planning Values .....	14
<b>3.0</b>	<b>INSPECTION AND INSTALLATION</b> .....	<b>16</b>
3.1	Equipment Inspection .....	16
3.1.1	Packing Material .....	16
3.2	Handling Unit on the Skid .....	17
3.3	Unpacking the Condenser—All Unit Sizes .....	18
3.4	Preparing a Condenser for Moving and Installation—Units with One to Four Fans .....	18
3.4.1	Attaching Legs, Removing the Skid and Attaching Slings—Units with One to Four Fans .....	18
3.5	Preparing a Condenser for Moving and Installation—Units with Six or Eight Fans .....	20
3.5.1	Attaching Legs, Removing the Skid and Attaching Slings—Units with Six or Eight Fans .....	20
3.6	Mounting the Condenser .....	22
3.7	Electrical Supply Preparation .....	22
3.7.1	Line Voltage Wiring .....	22
3.7.2	Low Voltage Control Wiring .....	24
3.7.3	Low Voltage Monitoring Wiring—VFD Condensers Only .....	25
3.8	Electrical Connections .....	25
3.8.1	VFD Control Condensers Only .....	25
3.8.2	Wye-Connected Power Supply .....	26
3.8.3	Delta-Connected Power Supply .....	26
3.9	Electrical Field Connection Descriptions .....	27
3.10	Refrigeration Piping Connections .....	30
3.10.1	Piping Guidelines .....	31
3.10.2	Field Piping Installation .....	32
3.10.3	Refrigerant Oil Addition Procedures .....	35
3.11	System Dehydration/Leak Test and Charging Procedures .....	35

---

<b>4.0</b>	<b>CHECKLIST FOR COMPLETED INSTALLATION</b>	<b>36</b>
4.1	Moving and Placing Equipment	36
4.2	Electrical	36
4.3	Piping	36
4.4	Other	36
<b>5.0</b>	<b>OPERATION</b>	<b>37</b>
5.1	Startup Checklist	37
5.2	Startup	37
<b>6.0</b>	<b>SYSTEM MAINTENANCE</b>	<b>38</b>
6.1	General Procedures	38
6.2	Special Procedures	39
6.2.1	Condenser Cleaning	39
6.2.2	Maintenance Inspection Checklist	40

---

## FIGURES

Figure 1	Liebert two-fan condenser . . . . .	1
Figure 2	Product model nomenclature . . . . .	2
Figure 3	Typical system configuration—indoor unit and outdoor condenser and field piping . . . . .	4
Figure 4	Condenser planning dimensional data—One-fan and two-fan units . . . . .	6
Figure 5	Condenser planning dimensional data—Three-fan and four-fan units . . . . .	7
Figure 6	Condenser planning dimensional data—Six- and eight-fan units . . . . .	8
Figure 7	Typical condenser footprint—dimensions . . . . .	9
Figure 8	Piping connection locations for 1-, 2-, 3- and 4-fan VFD Control and Fan Speed Condensers . . .	9
Figure 9	Piping connections for 1-, 2-, 3- and 4-fan Liebert Lee-Temp and Liebert Quiet-Line Condensers . . . . .	10
Figure 10	Piping connections for 6- and 8-fan Fan Speed Condensers . . . . .	10
Figure 11	Piping connections for 6- and 8-fan Liebert Lee-Temp and Liebert Quiet-Line Condensers . . .	11
Figure 12	Equipment recommended for handling a Liebert condenser . . . . .	16
Figure 13	Forklift position with one-fan to eight-fan condensers . . . . .	17
Figure 14	Lifting condenser off skid . . . . .	17
Figure 15	Removing protective material . . . . .	18
Figure 16	Attaching legs to one-fan to four-fan condensers . . . . .	19
Figure 17	Securing slings to one-fan to four-fan condensers for lifting off skid . . . . .	19
Figure 18	Remove skid, set condenser on floor . . . . .	20
Figure 19	Attach legs to six- and eight-fan condensers, remove from skid . . . . .	21
Figure 20	Rigging six-fan or eight-fan condenser for lifting into position . . . . .	21
Figure 21	Wye-connected power diagram . . . . .	26
Figure 22	Delta-connected power diagram . . . . .	26
Figure 23	Disconnecting EMC filter for operation with Delta-connected power . . . . .	27
Figure 24	Electrical field connections for Fan Speed Control Condensers . . . . .	27
Figure 25	Electrical field connections for VFD control condensers . . . . .	28
Figure 26	Electrical field connections for Liebert Lee-Temp control condensers . . . . .	29
Figure 27	VFD and Fan Speed Control condenser piping . . . . .	32
Figure 28	Liebert Lee-Temp head pressure control condenser piping . . . . .	33
Figure 29	General arrangement—Air cooled models with Liebert Lee-Temp control . . . . .	34

## TABLES

Table 1	Condenser shipping weights, dimensions and volume, approximate . . . . .	5
Table 2	Condenser physical data . . . . .	12
Table 3	Liebert Lee-Temp receiver weights and cross-reference to condenser . . . . .	13
Table 4	R-22 and R-407C refrigerant required, approximate . . . . .	14
Table 5	R-407C refrigerant required for DCSL616 condensers for Liebert XDC, approximate . . . . .	14
Table 6	R-410A refrigerant required, approximate . . . . .	14
Table 7	Interconnecting piping refrigerant charge . . . . .	15
Table 8	60Hz condenser data . . . . .	23
Table 9	60Hz condenser data, Liebert Quiet-Line (Liebert Lee-Temp controlled/fan-cycling) . . . . .	23
Table 10	50Hz condenser full load amp values . . . . .	24
Table 11	Liebert Lee-Temp receiver electrical data, 50Hz and 60Hz . . . . .	24
Table 12	Minimum recommended control circuit wire size, AWG, 60Hz models . . . . .	24
Table 13	Minimum recommended control circuit wire size, mm <sup>2</sup> , 50 Hz models . . . . .	25
Table 14	Troubleshooting . . . . .	41



---

## 1.0 INTRODUCTION

---


### 1.1 Product Description and Features

The Liebert condenser is low-profile direct-drive propeller fan-type air cooled unit suitable for mounting outdoors. It provides for the heat rejection of either one or two separate refrigeration circuits, matching heat rejection capacity varying with the outdoor ambient temperatures and with each corresponding compressors heat rejection requirements. Constructed with an aluminum cabinet and a copper-tube aluminum fin coil, the unit is quiet and corrosion resistant. The condenser is quickly and easily installed, because all internal wiring is completed at the factory with only electrical connections to be made at the job site. All electrical connections and controls are enclosed in an integral weatherproof section of the condenser.

**Figure 1** Liebert two-fan condenser



Figure 2 Product model nomenclature



## 1.2 Head Pressure Control Types

### 1.2.1 Fan Speed

Fan speed control utilizes a wave-chopper control to vary the air volume over the condenser coil, based on refrigerant head pressure. The fan motor next to the electrical panel (two fans on 6-fan and 8-fan models) is a single-phase, permanent split capacitor motor with motor speed adjusted in response to refrigerant pressure. The balance of fans on multi-fan units cycle on ambient thermostats. The control system provides refrigerant head pressure control for outdoor ambients as low as -20°F (-28.9°C).

### 1.2.2 Variable Frequency Drive

VFD Condenser control system utilizes a variable frequency drive, inverter duty fan motor operating from 0% to 100% motor RPM based on head pressure, sensed by refrigerant pressure transducers. VFD, ambient-temperature thermostat(s), motor overload protection and electrical control circuit are factory-wired in the integral control panel. VFD controls the fan adjacent to the connection end of the condenser and remains energized with active compressor operation. The balance of fans on multi-fan units cycle on ambient thermostats. This system provides refrigerant head pressure control for outdoor ambients as low as -20°F (-28.9°C).



### 1.2.3 Liebert Lee-Temp™ Refrigerant Control

The Liebert Lee-Temp head pressure control system is designed to maintain proper operating head pressures in outdoor temperatures down to -30°F (-34.4°C). The condensers utilize head pressure control valves, extra refrigerant and insulated refrigerant receivers with heater pads. It works by flooding the condenser coil with liquid refrigerant to a level that balances the system condensing requirements with the condenser coil surface available to reject the system heat. During the summer, the system requires the entire condenser coil surface for heat rejection and most of the refrigerant is stored in a receiver. In the winter, the same amount of heat can be rejected by only a fraction of the coil surface. As head pressure begins to fall, the control valve restricts the flow of liquid refrigerant exiting from the condenser. This extra liquid refrigerant reduces the effective condenser surface area available for heat transfer. The head pressure control valve also bypasses hot gas into the receiver to warm the liquid and maintain liquid pressure for proper operation of the expansion valve. Condenser fan controls are either fan cycling on ambient temperature or constant on. Liebert Lee-Temp control is required for Liebert Quiet-Line Condensers.

## 1.3 Sound Level Options

### 1.3.1 Standard Condenser

All Fan Speed and VFD Condensers are standard condensers with moderate operating sound levels. Liebert Lee-Temp condensers with standard-size coils matching Fan Speed and VFD coil sizes are standard sound level condensers.

### 1.3.2 Liebert Quiet-Line Condenser

Liebert Quiet-Line Condensers can help your facility meet the strictest noise codes and do so at less cost than traditional condensers with acoustical shielding. The Liebert Quiet-Line Condensers utilize the same reliable construction features of the standard condensers and have oversized coils and slower speed fan motors which yield the required heat rejection needed at significantly lower sound levels. Liebert Lee-Temp control is required for Liebert Quiet-Line Condensers.

## 1.4 Surge Protection Device


A Surge Protection Device (SPD) panel is standard in the VFD Condenser models only. Surge protection is necessary because the rooftop voltage supply often is not conditioned the same as the voltage supply inside the data center. The SPD is designed to protect the VFD from high voltage transients, up to 25kVA/phase.

An illuminated green LED indicates power supply is On and panel status is OK. An illuminated red LED indicates conditions require service and the SPD may require replacement to restore surge protection to the condenser.

## 1.5 Typical System Configurations

**Figure 3** shows a single refrigeration circuit diagram, displaying the indoor air conditioning unit, the outdoor condenser (VFD, Fan Speed Control or Liebert Lee-Temp) and field-supplied interconnection piping.

**Figure 3 Typical system configuration—indoor unit and outdoor condenser and field piping**



One or two refrigeration circuits may be provided. Single refrigeration circuit shown for clarity.

\* Components are not supplied by Liebert but are recommended for proper circuit operation and maintenance

Consult factory if Liebert Lee-Temp condenser is below the evaporator or if Fan Speed/VFD Control condenser is more than 15 ft (4.6m) below the evaporator.

- REFRIGERANT PIPING
- - - FIELD PIPING
- ▽ SERVICE / SCHRADER (ACCESS) CONNECTION NO VALVE CORE
- ∇ SERVICE / SCHRADER (ACCESS) CONNECTION WITH VALVE CORE

NOTES: Schematic representation shown. Do not use for specific connection locations.

DPN000798  
Rev. 3

## 2.0 SITE PREPARATION

### 2.1 Site Considerations

The condensers should be installed in a location offering maximum security and access for maintenance.

Avoid ground-level sites with public access and areas that contribute to heavy snow or ice accumulations. Utilize Piggyback condensers whenever interior building locations must be used. To ensure adequate air supply, Emerson recommends that condensers be installed in an area with clean air, away from loose dirt and foreign matter that might clog the coil. In addition, condensers should not be located near steam, hot air or fume exhausts. Also, the condensers should be located no closer than 3 feet (1m) from a wall, obstruction or adjacent unit.

The condenser must not be installed in a pit.

The condenser must be installed on a level surface to ensure proper refrigerant flow.

For roof installation, mount the condenser on suitable curbs or other supports in accordance with local codes.

Liebert Lee-Temp receiver tanks should be mounted on the condenser legs for proper operation.



Remote mounting of tanks must be within 10 feet of the condenser—Contact Emerson Application Engineering Department for assistance.

### 2.2 Dimensions and Weights

**Table 1 Condenser shipping weights, dimensions and volume, approximate**

Model	Number of Fans	Domestic Packaging			Export Packaging		
		Weight lb. (kg)	Dimensions (LxWxH) in. (mm)	Volume ft <sup>3</sup> (m <sup>3</sup> )	Weight lb. (kg)	Dimensions (LxWxH) in. (mm)	Volume ft <sup>3</sup> (m <sup>3</sup> )
083	1	330 (150)	59x30x51 (1500x760x1300)	52 (1.4)	415 (188)	60x31x52 (1520x790x1320)	56 (1.5)
104	1	350 (159)			435 (197)		
28K	1	350 (159)			435 (197)		
063	1	350 (159)			435 (197)		
165	2	490 (222)	97x30x51 (2460x760x1300)	86 (2.4)	690 (313)	98x31x52 (2490x790x1320)	91 (2.5)
205	2	560 (254)			760 (345)		
60K	2	560 (254)			760 (345)		
119	2	490 (222)			690 (313)		
127	2	560 (254)			760 (345)		
143	2	655 (297)			855 (388)		
251	3	590 (268)	139x30x51 (3530x760x1300)	123 (3.4)	870 (395)	140x31x52 (3560x790x1320)	131 (3.5)
308	3	760 (345)			1040 (472)		
90K	3	760 (345)			1040 (472)		
214	3	885 (401)			1165 (528)		
415	4	935 (424)	179x30x51 (4550x760x1300)	158 (4.4)	1235 (560)	180x31x52 (4570x790x1320)	168 (4.5)
510	4	1230 (558)			1530 (694)		
286	4	1185 (537)			1485 (674)		
616	6	1560 (708)	144x36x97 (3660x910x2460)	291 (8.3)	2010 (912)	145x37x97 (3680x940x2460)	301 (8.4)
409	6	1620 (735)			2070 (939)		
830	8	1930 (875)	184x36x97 (4670x910x2460)	372 (10.)	2430 (1102)	185x37x97 (4700x940x2460)	384 (10.)
1010	8	2910 (1321)			3410 (1548)		
572	8	2575 (1168)			3075 (1395)		


Figure 4 Condenser planning dimensional data—One-fan and two-fan units




Note:  
Overall height to the top of fan guard  
43-1/8" (1095mm)

Emerson recommends a clearance  
of 36" (915mm) on each side for  
proper operation and component  
access.

ANCHOR PLAN




ANCHOR PLAN



See Figure 7 for typical condenser  
footprint dimensions.

Figure 5 Condenser planning dimensional data—Three-fan and four-fan units



Note:  
Overall height to the top of fan guard  
43-1/8" (1095mm)

Emerson recommends a clearance of 36" (915mm) on each side for proper operation and component access.




Figure 6 Condenser planning dimensional data—Six- and eight-fan units





Figure 7 Typical condenser footprint—dimensions




Figure 8 Piping connection locations for 1-, 2-, 3- and 4-fan VFD Control and Fan Speed Condensers




Figure 9 Piping connections for 1-, 2-, 3- and 4-fan Liebert Lee-Temp and Liebert Quiet-Line Condensers






Figure 10 Piping connections for 6- and 8-fan Fan Speed Condensers





**Figure 11 Piping connections for 6- and 8-fan Liebert Lee-Temp and Liebert Quiet-Line Condensers**



DPN000670  
Rev. 01

Table 2 Condenser physical data

Model #	Number of Fans	Number of Circuits	Connection Size, OD, In.		Net Weight lb. (kg)
			Hot Gas	Liquid	
<b>Standard Models</b>					
083	1	1	7/8	5/8	295 (134)
104	1	1	1-1/8	5/8	315 (143)
104	1	2	7/8	1/2	315 (143)
165	2	1	1-1/8	7/8	425 (193)
165	2	2	7/8	5/8	425 (193)
205	2	1	1-1/8	7/8	495 (225)
205	2	2	1-1/8	7/8	495 (225)
251	3	1	1-1/8	7/8	500 (227)
251	3	2	1-1/8	7/8	500 (227)
308	3	1	1-5/8	1-1/8	670 (304)
308	3	2	1-3/8	1-1/8	670 (304)
415	4	1	1-3/8	1-1/8	840 (381)
415	4	2	1-3/8	1-1/8	840 (381)
510	4	1	2-1/8	1-5/8	1190 (540)
510	4	2	1-5/8	1-1/8	1190 (540)
616 <sup>1</sup>	6	1	(2) 1-5/8	(2) 1-1/8	1380 (626)
616	6	2	1-5/8	1-1/8	1380 (626)
830	8	2	1-3/8	1-1/8	1750 (794)
1010	8	2	2-1/8	1-5/8	2640 (1197)
<b>Liebert Quiet-Line Models</b>					
063	1	1	1-1/8	5/8	315 (143)
119	2	1	1-1/8	7/8	425 (193)
119	2	2	7/8	5/8	425 (193)
127	2	1	1-1/8	7/8	495 (225)
127	2	2	1-1/8	7/8	495 (225)
143	2	1	1-1/8	7/8	515 (234)
143	2	2	1-1/8	7/8	515 (234)
214	3	1	1-5/8	1-1/8	840 (381)
214	3	2	1-1/8	7/8	840 (381)
286	4	1	2-1/8	1-1/8	1105 (501)
286	4	2	1-1/8	7/8	1105 (501)
409	6	2	1-5/8	1-1/8	1380 (626)
572	8	2	2-1/8	1-1/8	2430 (1102)
<b>R-410A Models</b>					
28K	1	1	1-1/8	5/8	325 (147)
60K	2	1	1-1/8	5/8	475 (215)
90K	3	1	1-1/8	5/8	675 (306)

1. Interconnection piping (field-supplied and installed) required. Configure piping for parallel refrigerant flow between condenser sections.

**Table 3** Liebert Lee-Temp receiver weights and cross-reference to condenser

Condenser Model #	Receiver Part #	Receivers per Condenser	Weight per Receiver lb. (kg)
<b>Standard Models</b>			
DCSL083	1C19982P1	1	100 (45)
DCSL104	1C19982P1		100 (45)
DCSL165	W-0050		125 (57)
DCSL205	W-0050		125 (57)
DCSL251	W-0050		125 (57)
DCSL308	W-0060		145 (66)
DCSL415	185011P1		260 (118)
DCSL616	W-0410 <sup>1</sup>		200 (91)
DCSL616	179701P1 <sup>2</sup>		424 (192)
DCDL104	1C19982P1	2	100 (45)
DCDL165	1C19982P1		100 (45)
DCDL205	W-0050		125 (57)
DCDL251	1C19982P1		100 (45)
DCDL308	W-0050		125 (57)
DCDL415	W-0060		145 (66)
DCDL510	W-0410		200 (91)
DCDL616	W-0060		145 (66)
DCDL830	185011P1		260 (118)
<b>Liebert Quiet-Line Models</b>			
DCSL063	1C19982P1	1	100 (45)
DCST119	W-0050		125 (57)
DCSL127	W-0050		125 (57)
DCSL143	W-0060		145 (66)
DCST214	W-0410		200 (91)
DCST286	W-0410		200 (91)
DCDL119	1C19982P1	2	100 (45)
DCDL127	1C19982P1		100 (45)
DCDL143	W-0050		125 (57)
DCDT214	W-0050		125 (57)
DCDL286	W-0060		145 (66)
DCDT409	W-0410		200 (91)
DCDT572	W-0410	200 (91)	
<b>R-410A Models</b>			
DCSL28K	195315P1	1	125 (57)
DCSL60K	195316P1		145 (66)
DCSL90K	196702P1		200 (91)

1. Matchup for 35 to 105°F (2 to 41°C) design temperature range.

2. Matchup for -30 to 105°F (-34 to 41°C) design temperature range.

## 2.3 Refrigerant Planning Values

Planning for the refrigerant requirements of the completed system is the addition of the charges from Indoor Unit, Condenser (including Liebert Lee-Temp receiver, if used) and the interconnecting piping. **Tables 4 and 7** provide the approximate charge required for the condensers and the interconnecting piping. Consult indoor unit manuals for indoor unit charge requirements.

These values can be used for obtaining adequate refrigerant for the system, but should not be used for final charging. Consult indoor unit manual for charging procedures.

**Table 4 R-22 and R-407C refrigerant required, approximate**

Standard Condenser Models	Approximate R-22 Refrigerant Needed				Approximate R-407C Refrigerant Needed			
	Single Circuit lb. (kg)		Dual Circuit lb./circuit (kg/circuit)		Single Circuit lb. (kg)		Dual Circuit lb./circuit (kg/circuit)	
	FSC or VFD	Lee-Temp (includes receiver)	FSC or VFD	Lee-Temp (includes receiver)	FSC or VFD	Lee-Temp (includes receiver)	FSC or VFD	Lee-Temp (includes receiver)
83	5 (2.3)	27 (12.3)	3 (1.4)	N/A	5 (2.3)	26 (11.8)	3 (1.4)	N/A
104	8 (3.6)	39 (17.7)	7 (3.2)	21 (9.5)	8 (3.6)	37 (16.8)	7 (3.2)	20 (9.0)
165	15 (6.8)	53 (24.0)	5 (2.3)	27 (12.3)	15 (6.8)	50 (22.7)	5 (2.3)	26 (11.8)
205	20 (9.1)	76 (34.5)	7 (3.2)	56 (25.3)	19 (8.6)	72 (32.7)	7 (3.2)	54 (24.4)
251	19 (8.6)	75 (34.0)	10 (4.6)	38 (17.2)	18 (8.2)	71 (32.2)	10 (4.6)	36 (16.3)
308	29 (13.2)	113 (51.3)	11 (5.0)	58 (26.3)	28 (12.7)	107 (48.5)	11 (5.0)	55 (24.9)
415	54 (24.5)	210 (95.0)	25 (11.3)	107 (48.4)	51 (23.1)	200 (90.8)	24 (10.9)	102 (46.2)
510	72 (32.7)	N/A	30 (13.6)	149 (67.6)	68 (30.8)	N/A	29 (13.2)	142 (64.4)
616	N/A	N/A	27 (12.3)	113 (51.3)	N/A	See <b>Table 5</b>	26 (11.8)	108 (49.0)
830	N/A	N/A	53 (24)	210 (95.1)	N/A	N/A	51 (23.1)	200 (90.8)
1010	N/A	N/A	60 (27.2)	154 (69.9)	N/A	N/A	57 (25.9)	147 (66.7)
<b>Liebert Quiet-Line Condenser Models</b>								
63	N/A	39 (17.7)	N/A	N/A	N/A	37 (16.8)	N/A	N/A
119	N/A	50 (22.7)	N/A	27 (12.3)	N/A	48 (21.8)	N/A	26 (11.8)
127	N/A	76 (34.5)	N/A	38 (17.2)	N/A	72 (32.6)	N/A	36 (16.3)
143	N/A	126 (57.2)	N/A	64 (29.0)	N/A	120 (54.5)	N/A	61 (27.7)
214	N/A	161 (73.0)	N/A	81 (36.7)	N/A	153 (69.4)	N/A	77 (34.9)
286	N/A	196 (88.9)	N/A	125 (56.7)	N/A	186 (84.4)	N/A	119 (54.0)
409	N/A	N/A	N/A	152 (68.9)	N/A	N/A	N/A	148 (67.2)
572	N/A	N/A	N/A	196 (88.9)	N/A	N/A	N/A	186 (84.4)

**Table 5 R-407C refrigerant required for DCSL616 condensers for Liebert XDC, approximate**

Model #	Liebert Lee-Temp Receiver	Receiver Tank Length, in. (mm)	Refrigerant Per Circuit (inc. receiver), lb. (kg)
DCSL616	W-0410	48 (1219)	164 (75)
	179701P1	96 (2438)	254 (115.2)

**Table 6 R-410A refrigerant required, approximate**

Single Circuit Model	VFD lb. (kg)	Liebert Lee-Temp (inc. receiver) lb. (kg)
28K	7 (3.2)	41 (18.6)
60K	16 (7.3)	75 (34.0)
90K	25 (11.3)	109 (49.4)

**Table 7 Interconnecting piping refrigerant charge**

Line Size, O.D., in.	R-22, lb./100 ft. (kg/30m)		R-407C, lb./100 ft. (kg/30m)		R-410A, lb./100 ft. (kg/30m)	
	Liquid Line	Hot Gas Line	Liquid Line	Hot Gas Line	Liquid Line	Hot Gas Line
3/8	3.8 (1.7)	—	3.7 (1.7)	—	—	—
1/2	7.3 (3.3)	—	6.9 (3.1)	—	5.0 (2.1)	—
5/8	11.7 (5.3)	2.1 (1.0)	11.0 (5.0)	2.2 (1.0)	10.0 (4.2)	1.1 (0.51)
3/4	16.6 (7.5)	3.0 (1.4)	15.7 (7.1)	3.1 (1.3)	13.0 (5.7)	1.5 (0.67)
7/8	24.4 (11.1)	4.4 (2.0)	23.0 (10.4)	4.5 (1.9)	—	2.3 (1.0)
1-1/8	41.4 (18.9)	7.8 (3.5)	39.3 (17.8)	7.8 (3.5)	—	3.9 (1.8)
1-3/8	63.3 (28.7)	11.8 (5.4)	59.8 (27.1)	11.8 (5.4)	—	—
1-5/8	—	16.7 (7.6)	—	16.7 (7.6)	—	—

## 3.0 INSPECTION AND INSTALLATION

### 3.1 Equipment Inspection

Before unpacking the condenser, verify that the labeled equipment matches the bill of lading. Carefully inspect all items for damage, either visible or concealed. Report any damage immediately to the carrier and your local Emerson representative. File a damage claim with the carrier and send a copy to your local Emerson representative.

#### 3.1.1 Packing Material

All material used to package this unit is recyclable. Please save it for future use or dispose of the material appropriately.



## SAFETY INFORMATION



### WARNING

Risk of improper handling. Can cause equipment damage, injury or death.

Read all of the following instructions before attempting to move, lift, remove packaging from or preparing unit for installation.



### CAUTION

Risk of sharp edges, splinters and exposed fasteners. Can cause personal injury.

Only properly trained and qualified personnel wearing appropriate safety headgear, gloves, shoes and glasses should attempt to move, lift, remove packaging from or prepare unit for installation.

### NOTICE

Risk of overhead interference. Can cause unit and/or structure damage.  
Refer to the installation plans prior to moving the unit to verify clearances.


### NOTICE

Risk of improper forklift handling. Can cause unit damage.  
Keep tines of the forklift level and at a height suitable to fit under the skid.


### NOTICE

Risk of improper storage. Can cause unit damage. Keep unit upright and protected from contact damage.


Figure 12 Equipment recommended for handling a Liebert condenser



Forklift



Lift Beam, Slings and Spreader Bars




Crane

### 3.2 Handling Unit on the Skid

Transport the unit using a forklift or a crane with sling and spreader bars.

- If using a forklift, make sure the forks (if adjustable) are spread to the widest allowable distance to still fit under the skid.
- Type of forklift used will be dependant on the terrain the unit is be moved across during handling.
- Minimum forklift fork length:
  - for one-fan and two-fan units—48" (1219mm)
  - for three-fan and four-fan units—72" (1829mm)
  - for six fan units—72" (1829mm)
  - for 8 fan units—96" (2438mm)
- When moving the packaged unit, do not lift the unit any higher than 6" (152mm) off the ground. If the unit must be lifted higher than 6" (152mm), great care must be exercised and all personnel not involved in moving the unit must be at least 20' (5m) from the lift point of the unit.

**Figure 13 Forklift position with one-fan to eight-fan condensers**




Three-fan unit shown.  
Positioning for other Liebert  
condensers are the same.



- When using a fork lift to off-load or move for installation, it is recommended to lift one narrow end off the ground no more than 6" (152mm). Use the forklift to push or pull the unit.
- When using a crane to lift the unit from a flat bed or to move for installation, it is recommended using slings rated for the unit weight.
- Spreader bars are to be used for sling stability and to prevent unit pinching. Make sure spreader bars are wider than the unit.
- Slings are to be placed near the ends of the unit, under the top deck boards of the skid.

**Figure 14 Lifting condenser off skid**




Three-fan unit shown.  
Positioning for other Liebert  
condensers are the same.

### 3.3 Unpacking the Condenser—All Unit Sizes

To unpack a condenser with one to eight fans:

1. Remove the exterior stretch wrap packaging material from around the unit.
2. Remove corner and side foam planks from around the unit.
3. Remove the steel bands holding the unit to the skid.
4. Set unit legs aside, but accessible.
5. Remove corrugated panels covering the coil(s) of the unit.

Figure 15 Removing protective material



### 3.4 Preparing a Condenser for Moving and Installation—Units with One to Four Fans


The following procedure is one recommended method for removing a Liebert condenser from its shipping skid. Other methods may be used, provided that they are safe for personnel, the condenser and equipment.

#### 3.4.1 Attaching Legs, Removing the Skid and Attaching Slings—Units with One to Four Fans

1. Attach legs to the unit at indicated locations.  
Use the fasteners provided with the legs.  
Recommended tools for attachment is a 5/8" socket and ratchet.  
More legs may be available for installation than shown, this will be dependent on unit type and number of fans.



Figure 16 Attaching legs to one-fan to four-fan condensers




2. Place slings around the unit:

- **One-, two- and three-fan units:** place slings against the inside of the attached legs.
- **Four-fan units:** place slings against the outside of the attached eye bolts.

Slings are to be placed between the unit and the top deck boards of the skid.

Use spreader bars, lift beam and crane to lift the unit off the skid. Make sure spreader bars wider than the unit.

Figure 17 Securing slings to one-fan to four-fan condensers for lifting off skid




3. Lift the unit 24" (610mm) off the top deck of the skid.

Remove the skid from under the unit.

A mechanized method is preferred, but if not available use a minimum of four properly protected individuals to turn the unit upright so that the legs point down.

Unit legs are to be pointing toward the ground.

Figure 18 Remove skid, set condenser on floor



1. Set the upright unit on the ground so the legs support unit weight.  
Remove the straps from around unit.
  - **One-, two- and three-fan units:** route the straps through the large holes on the side of the legs. Spreader bars are still required. Make sure spreader bars are wider than the unit.
  - **Four-fan units:** use the eye bolts on top of the unit to secure straps or chains.

The unit is now ready to be lifted and moved to its installation location.


### 3.5 Preparing a Condenser for Moving and Installation—Units with Six or Eight Fans

The following procedure is one recommended process for removing a Liebert condenser from its shipping skid. Other methods may be used, provided that the methods are safe for personnel, the condenser and equipment.

#### 3.5.1 Attaching Legs, Removing the Skid and Attaching Slings—Units with Six or Eight Fans


1. Attach upper most legs to the unit at indicated locations.  
Use four (4) fasteners per leg. Fasteners are provided with the legs.  
Quantity of legs per side may vary per unit type and number of fans.  
Recommended tools for attachment is a 5/8" socket and ratchet.
2. Attach slings or chains to the top side of the unit lift rails.  
Mechanically lower the unit in order to rest on the attached legs.  
Make sure not to damage the opposite side of the unit.
3. Move the slings or chains to the lift rail side resting on the skid.  
Mechanically lift the unit to a point where the side being lifted is just high enough to allow for safe attachment of the remaining unit legs.  
Move the skid out the way.
4. Use the support channels located under the unit to attach straps or chains. Spreader bars are still required. Make sure spreader bars are wider than the unit.

Figure 19 Attach legs to six- and eight-fan condensers, remove from skid



The unit is ready to be lifted and moved to its installation location.

Figure 20 Rigging six-fan or eight-fan condenser for lifting into position



### 3.6 Mounting the Condenser

The condenser must be installed so that it is level within 1/2" (13mm) to ensure proper refrigerant flow. For roof installation, mount the condenser on suitable curbs or other supports; follow all local and national codes. Secure the legs to the mounting surface using a field-supplied 1/2" (13mm) diameter bolt in each of the two 9/16" (14mm) holes in each leg. See **Figures 4, 5 and 6** for anchor dimensions.

### 3.7 Electrical Supply Preparation

Line voltage electrical service is required for all models. Refer to equipment nameplate regarding wire size and circuit protection requirements. Electrical service must conform to national and local electrical codes. Refer to **Figures 24, 25 and 26** for electrical service entrances into unit. Refer to electrical schematic when making connections.

Each unit is shipped from the factory with all internal unit wiring completed.



#### **WARNING**

Risk of electric shock. Can cause injury or death.

Disconnect all local and remote electrical power supplies before working within the electrical enclosure.

The line side of the disconnect remains energized when the disconnect is Off.

Use a voltmeter to verify that the electrical power is Off before performing any electrical and/or mechanical service and/or maintenance operations.



#### **WARNING**

Risk of high speed moving parts. Can cause injury or death.

The fan(s) blades can start to rotate unexpectedly when the power is On. Disconnect all local and remote electrical power supplies before working within the fan compartment.

Use a voltmeter to verify that the electrical power is Off before performing any electrical and/or mechanical service and/or maintenance operations.

Each unit is shipped from the factory with all internal unit wiring completed. Refer to the electrical schematic supplied with the condenser when making line voltage supply, low voltage indoor unit interlock and any low voltage alarm connections. All wiring must be done in accordance with all applicable local, state and national electrical codes.

#### 3.7.1 Line Voltage Wiring



#### **WARNING**

Risk electrical fire and short circuit. Can cause property damage, injury or death.

Select and install the electrical supply wire and overcurrent protection device(s) according to the specifications on the unit nameplate(s), per the instructions in this manual and according to the applicable national, state and local code requirements. Use copper conductors only. Make sure all electrical connections are tight. Unit-specific wiring diagrams are provided on each unit.

Condenser-rated voltage should be verified with available power supply before installation. Refer to the unit's electrical schematic and serial tag for specific electrical requirements.

Line voltage electrical service is required for all condensers at the location of the condenser. The power supply does not necessarily have to be the same voltage supply as required by the indoor unit connected to the condenser. See the unit's serial tag for specific condenser electrical requirements. A unit disconnect is standard on VFD and Liebert Quiet-Line Condensers and is optional on Fan Speed Control and standard Liebert Lee-Temp condensers. However, a site disconnect may be required per local code to isolate the unit for maintenance. Route the supply power to the site disconnect switch and then to the unit. Route the conduit through the hole provided in the cabinet. Connect earth ground to lug provided near terminal board.



**NOTE**

Liebert Lee-Temp and Liebert Quiet-Line Condensers require a separate line voltage electrical supply for the heated receivers. See **Table 11** for power requirements.

**Table 8 60Hz condenser data**

Model #	83, 104, 28K			165, 205, 60K			251, 308, 90K			415, 510			616			830, 1010			
# of Fans	1			2			3			4			6			8			
Input Voltage	ph	FLA	WSA	OPD	FLA	WSA	OPD	FLA	WSA	OPD	FLA	WSA	OPD	FLA	WSA	OPD	FLA	WSA	OPD
<b>Fan Speed Controlled</b>																			
208/230	1	4.8	6.0	15	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
460		2.5	3.1	15	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
575		1.9	2.4	15	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
208/230	3	—	—	—	8.3	9.5	15	11.8	13.0	15	15.3	16.5	20	23.6	24.8	30	30.6	31.8	40
460		—	—	—	4.2	4.8	15	5.9	6.5	15	7.6	8.2	15	11.8	12.4	15	15.2	15.8	20
575		—	—	—	3.3	3.8	15	4.7	5.2	15	6.1	6.6	15	9.4	9.9	15	12.2	12.7	15
<b>VFD Controlled</b>																			
208/230	3	3.7	4.6	15	7.2	8.1	15	10.7	11.6	15	14.2	15.1	20	N/A	N/A	N/A	N/A	N/A	N/A
460		1.8	2.3	15	3.5	4.0	15	5.2	5.7	15	6.9	7.4	15	N/A	N/A	N/A	N/A	N/A	N/A
<b>Liebert Lee-Temp Controlled/Fan-Cycling</b>																			
208/230	3	3.5	4.4	15	7.0	7.9	15	10.5	11.4	15	14.0	14.9	20	21.0	21.9	25	28.0	28.9	35
460		1.7	2.1	15	3.4	3.8	15	5.1	5.5	15	6.8	7.2	15	10.2	10.6	15	13.6	14.0	20
575		1.4	1.8	15	2.8	3.2	15	4.2	4.6	15	5.6	6.0	15	8.4	8.8	15	11.2	11.6	15

FLA = Full Load Amps; WSA = Wire Size Amps; OPD = Maximum Overcurrent Protection Device

**Table 9 60Hz condenser data, Liebert Quiet-Line (Liebert Lee-Temp controlled/fan-cycling)**

Model #	ph	63			119, 127, 143			214			286			409			572		
# of Fans	1			2			3			4			6			8			
Input Voltage	ph	FLA	WSA	OPD	FLA	WSA	OPD	FLA	WSA	OPD	FLA	WSA	OPD	FLA	WSA	OPD	FLA	WSA	OPD
208/230	3	1.8	2.3	15	3.6	4.1	15	5.4	5.9	15	7.2	7.7	15	10.8	11.3	15	14.4	14.9	20
460		0.9	1.1	15	1.8	2.0	15	2.7	2.9	15	3.6	3.8	15	5.4	5.6	15	7.2	7.4	15
575		0.7	0.9	15	1.4	1.6	15	2.1	2.3	15	2.8	3.0	15	4.2	4.4	15	5.6	5.8	15

FLA = Full Load Amps; WSA = Wire Size Amps; OPD = Maximum Overcurrent Protection Device

**Table 10 50Hz condenser full load amp values**

Condenser Control Type		Fan Speed Controlled		VFD Controlled		Lee Temp Controlled/Fan-Cycling		Liebert Quiet-Line (Liebert Lee Temp Controlled/Fan-Cycling)		
Model #	# of Fans	Input Voltage - Phase		Input Voltage - Phase		Input Voltage - Phase		Model #	Input Voltage - Phase	
		200/220-1	380/415-3	200/230-3	380/415-3	200/230-3	380/415-3		200/230-3	380/415-3
83, 104	1	4.0	-	3.7	1.8	3.5	1.7	63	1.8	0.9
165, 205	2	—	3.7	7.2	3.5	7.0	3.4	119, 127, 143	3.6	1.8
251, 308	3	—	5.4	10.7	5.2	10.5	5.1	214	5.4	2.7
415, 510	4	—	7.1	14.2	6.9	14.0	6.8	286	7.2	3.6
616	6	—	10.8	—	—	21.0	10.2	409	10.8	5.4
830, 1010	8	—	14.2	—	—	28.0	13.6	572	14.4	7.2

**Table 11 Liebert Lee-Temp receiver electrical data, 50Hz and 60Hz**

Rated Voltage - Single Phase	120			200/208/230		
Watts/Receiver	150	300	450	150	300	450
Full Load Amps	1.4	2.8	4.2	0.7	1.4	2.1
Wire Size Amps	1.8	3.5	5.3	0.9	1.8	2.7
Maximum Overcurrent Protection Device, Amps	15	15	15	15	15	15

The Liebert Lee-Temp receiver requires a separate power feed for heaters. The condenser is not designed to supply power to the receiver.

**3.7.2 Low Voltage Control Wiring**

**NOTICE**

Risk of control malfunction. Can cause improper unit operation. Make sure that all low voltage electrical wiring has been performed per the schematic diagram provided and that all low voltage wiring connections are tight.

A control interlock between the condenser and the indoor cooling units is required. Field-supplied copper wire is required for connection between like-numbered terminals 70 & 71 on both units. Wiring must be sized and selected for insulation case per NEC and other local codes. See **Tables 12 and 13** for recommended wire sizing for control wiring runs up to 150 ft (45.7m). Contact the factory for assistance with longer wiring runs. See **Figures 24, 25 and 26** and indoor unit manual for location of terminals on condensers and indoor units.

**Table 12 Minimum recommended control circuit wire size, AWG, 60Hz models**

Control Wire Run ft (m)	Control Type													
	VFD & Fan Speed Controlled						Liebert Lee-Temp Only		Liebert Lee-Temp Controlled with Fan-Cycling					
	Number of Fans						Number of Fans		Number of Fans					
	1	2	3	4	6	8	1-4	6 & 8	2	3	4	6	8	
0-25 (0-7.6)	16	16	16	16	16	16	16	16	16	16	16	16	16	
26-50 (7.9-15.2)			16	16	14	16				16	16	16		
51-75 (15.5-22.8)			16	16	14	14				16	16	16	16	
76-100 (23.2-30.4)			16	16	12	12				16	16	16	16	
101-125 (30.8-38.1)			16	14	10	12				16	14	16	14	
126-150 (38.4-45.7)			14	14	10	10				14	14	14	14	

Table based on 16AWG min. wire size, 0.4A per contactor, 1 to 1.5V maximum drop & 104°F (40°C) average ambient temperature

**Table 13 Minimum recommended control circuit wire size, mm<sup>2</sup>, 50 Hz models**

Control Wire Run, M (ft)	Control Type												
	VFD & Fan Speed Controlled						Liebert Lee-Temp Only		Liebert Lee-Temp Controlled with Fan-Cycling				
	Number of Fans						Number of Fans		Number of Fans				
	1	2	3	4	6	8	1-4	6 & 8	2	3	4	6	8
0-7.6 (0-25)	1.0	1.0	1.0	1.0	1.5	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
7.9-15.2 (26-50)			1.0	1.0	2.5	2.5		1.0	1.0	1.0	1.0	1.0	1.0
15.5-22.8 (51-75)			1.5	1.5	4.0	4.0		1.0	1.0	1.5	1.5	1.5	1.5
23.2-30.4 (76-100)			1.5	2.5	6.0	4.0		1.0	1.0	1.5	2.5	1.5	2.5
30.8-38.1 (101-125)			2.5	2.5	6.0	6.0		1.5	1.5	2.5	2.5	2.5	2.5
38.4-45.7 (126-150)			2.5	4.0	6.0	6.0		1.5	1.5	2.5	4.0	2.5	4.0

Table based on 1.0mm<sup>2</sup> min. wire size, 0.5A per contactor, 1 to 1.5V maximum drop & 40 °C (104 °F) average ambient temperature

**3.7.3 Low Voltage Monitoring Wiring—VFD Condensers Only**

Condensers with monitoring terminals may be wired with Class 1 copper wire to the indoor cooling unit or other monitoring panel. Wiring must be sized so that the voltage drop in the circuit does not exceed 1 volt. Dry contacts close when a monitored event occurs. Consult condenser electrical schematic, supplied with the unit, for details.

Contact closure on VFD Drive monitoring terminals indicates a permanent VFD fault. A factory-programmed VFD must be used as the replacement.

Contact closure on SPD monitoring terminals may indicate unit trouble ranging from electrical supply issues to SPD replacement required. A properly trained and qualified electrician is required.

**3.8 Electrical Connections**

Electrical service is required for all models. Electrical service shall conform to national and local electrical codes. Refer to equipment nameplate regarding wire size and circuit protection requirements. Refer to electrical schematic when making connections. Refer to **Figures 24, 25** and **26** for electrical service entrances into unit.

A manual electrical disconnect switch should be installed in accordance with local codes. Consult local codes for external disconnect requirements.



**WARNING**

Risk of electric shock. Can cause injury or death.

Disconnect all local and remote electric power supplies before working in the unit. Unit contains lethal voltage in some circuits. Use voltmeter to make sure power is turned Off before making any electrical connections.



**NOTE**

*Installation and service of this equipment should be done only by properly trained and qualified personnel who have been specially trained in the installation of air conditioning equipment.*



**NOTE**

*Use copper wiring only. Make sure that all connections are tight.*

**3.8.1 VFD Control Condensers Only**

The installer/startup technician must determine the type of 3-phase supply power being used for the VFD Control Condenser: Wye-connected power or Delta- connected power.


Wye-connected power has two different voltages that can be measured: Phase-to-Phase voltage (this is equal to the nominal input voltage) and Phase-to-Neutral voltage (typically used for small single phase loads (120VAC or 277VAC). See **Figure 21**.

Delta-connected power only has one voltage level that can be measured: Phase-to-Phase. See **Figure 22**.

### 3.8.2 Wye-Connected Power Supply


No control changes are required if the Liebert VFD Control Condenser will be operated with Wye-connected power.

Figure 21 Wye-connected power diagram



### 3.8.3 Delta-Connected Power Supply

Figure 22 Delta-connected power diagram




#### Disconnect EMC Filter for Delta-Connected Power

Installer/startup technician needs to disconnect the EMC filter on the VFD to ensure proper operation if the Liebert VFD Control Condenser will be operated with Delta-connected power.

1. Disconnect the power supply before working on the unit.
2. Open the electrical panel cover and locate the VFD (Refer to **Figure 25**).
3. Using **Figure 23**, locate the small black plastic tab immediately to the right of the wiring connection block of the VFD control
4. Pull the tab to fully extend it, disconnecting the EMC filter from the circuit.




Figure 23 Disconnecting EMC filter for operation with Delta-connected power




### 3.9 Electrical Field Connection Descriptions

Figure 24 Electrical field connections for Fan Speed Control Condensers




**NOTE: Refer to specification sheet for full load amp. and wire size amp. ratings.**

Figure 25 Electrical field connections for VFD control condensers



**NOTE: Refer to specification sheet for full load amp. and wire size amp. ratings.**

Figure 26 Electrical field connections for Liebert Lee-Temp control condensers



**NOTE: Refer to specification sheet for full load amp. and wire size amp. ratings.**

### 3.10 Refrigeration Piping Connections



#### WARNING

Risk of explosive discharge from high-pressure refrigerant. Can cause equipment damage, injury or death. Relieve pressure before working with piping.



#### WARNING

Risk of refrigerant system rupture or explosion from overpressurization. Can cause equipment damage, injury or death.

If a pressure relief device is not provided with the condenser unit, the system installer must provide and install a discharge pressure relief valve rated for a maximum of 500 psig (34bar) in the high side refrigerant circuit. Do not install a shutoff valve between the compressor and the field installed relief valve.

One or more additional pressure relief valves are required downstream of any and all field installed isolation valves as shown in **Figures 3** and **29**. Do not isolate any refrigerant circuits from overpressurization protection.



#### NOTE

*POE (polyol ester) oil, required with R407C/R410A and used with some R22 systems, is much more hygroscopic than mineral oils. This means that POE oil absorbs water at a much faster rate when exposed to air than previously used mineral oils. Because water is the enemy of a reliable refrigeration system, extreme care must be used when opening systems during installation or service. If water is absorbed into the POE oil, it will not be easily removed and will not be removed through the normal evacuation process. If the oil is too wet, it may require an oil change. POE oils also have a property that makes them act as a solvent in a refrigeration system.*

#### NOTICE

Risk of improper installation and system contamination. Can degrade system performance and damage components.

Maintaining system cleanliness is extremely important to properly complete installation and to maintain system warranty. Failure to maintain system cleanliness during piping installation will clog filter driers and adversely affect other system components such as compressors and expansion valves. Refer to **3.10.1 - Piping Guidelines** for details.

### 3.10.1 Piping Guidelines

Indoor units and condensers both ship with nitrogen holding charges. Do not vent the condenser until all refrigerant piping is in place, ready for connection to indoor unit and condenser.

- Use copper piping with a brazing alloy with a minimum temperature of 1350°F (732°C), such as Sil-Fos. Avoid soft solders such as 50/50 or 95/5.
- Use a flow of dry nitrogen through the piping during brazing to prevent formation of copper oxide scale inside the piping. When copper is heated in the presence of air, copper oxide forms. POE oil will dissolve these oxides from inside the copper pipes and deposit them throughout the system, clogging filter driers and affecting other system components.
- A pure dry nitrogen flow of 1-3 ft<sup>3</sup>/min (0.5-1.5 l/s) inside the pipe during brazing is sufficient to displace the air. Control the flow using a suitable metering device.
- Ensure that the tubing surfaces to be brazed are clean and that the ends of the tubes have been carefully reamed to remove any burrs.
- Ensure that all loose material has been cleaned from inside the tubing before brazing.
- Protect all refrigerant line components within 18" (460mm) of the brazing site by wrapping them with wet cloth or suitable heat sink compound.
- Isolate piping from building using vibration isolating supports.
- Refer to indoor unit user manual for appropriate piping sizes.
- Install traps on the hot gas (discharge) lines at the bottom of any rise over 5 feet high. If the rise exceeds 25 feet (7.5m), then install a trap in 20 foot (6m) increments or evenly divided.
- Pitch horizontal hot gas piping at a minimum rate of 1/2" per 10 ft. (42mm per 10m) so that gravity will aid in moving oil in the direction of refrigerant/oil flow.
- Consult factory if Liebert Lee-Temp condenser is below the evaporator or if Fan Speed/VFD Control Condenser is more than 15 ft (4.6m) below the evaporator.
- Consult factory if piping run exceeds 150 feet (46m) equivalent length.
- Keep piping clean and dry, especially on units with POE oil (R407C, R410A or R22 refrigerant).
- Avoid piping runs through noise-sensitive areas.
- Do not run piping directly in front of indoor unit discharge airstream.
- Refrigerant oil – do not mix oil types or viscosities. Consult indoor unit for refrigerant type and oil requirements.



#### NOTE

*Failure to use compressor oils recommended by compressor manufacturer will void compressor warranty. Consult Emerson or the compressor manufacturer for further recommendations or if you have questions about compressor oils.*

*Refer to ASHRAE Refrigeration Handbook for general good practices for refrigeration piping. A pressure relief valve is provided with Liebert Lee-Temp condensers. A fusible plug is provided on Liebert Fan Speed Control and VFD condensers. The Liebert indoor cooling unit has a factory-installed high-pressure safety switch in the high side refrigerant circuit.*

### 3.10.2 Field Piping Installation

One discharge line and one liquid line must be field-installed for each circuit of the indoor unit and the outdoor condenser(s). Dual circuit condensers are available for most dual circuit indoor unit applications. Refer to **Figures 27, 28 and 29** below for additional field-installed piping needed at the condenser. This piping is needed for proper system performance and for installation/interconnecting receivers and head pressure control valves for Liebert Lee-Temp systems.



**NOTE**

*Keep the evaporator unit and condenser closed with their factory charge of dry nitrogen while all field piping is installed. Keep the field piping clean and dry during installation, and do not allow it to stand open to the atmosphere.*

*When all the field interconnecting piping is in place, vent the condenser's dry nitrogen charge and connect to the field piping. Finally, vent the evaporator unit's dry nitrogen charge and make its piping connections last.*

*Follow all proper brazing practices, including a dry nitrogen purge to maintain system cleanliness. Refer to 3.10.1 - Piping Guidelines.*

**Figure 27 VFD and Fan Speed Control condenser piping**







Figure 28 Liebert Lee-Temp head pressure control condenser piping



DPN000669  
Rev. 2



Figure 29 General arrangement—Air cooled models with Liebert Lee-Temp control



**Single Circuit Shown**

- ===== Factory Piping
- Optional Piping
- Field Piping

\* Components are not supplied by Liebert but are recommended for proper circuit operation and maintenance.  
 \*\* Components supplied by Liebert and must be field-installed.  
 \*\*\* Various compressor types may be available.

DPN000681  
 Rev. 0



### **3.10.3 Refrigerant Oil Addition Procedures**

Consult the indoor unit's user or installation manual to determine whether additional oil is required for each circuit. Factors such as compressor, condenser type, piping lengths and total circuit refrigerant charge influence this requirement.

### **3.11 System Dehydration/Leak Test and Charging Procedures**

Procedures for leak check and evacuation of the entire refrigeration system are contained in the indoor unit's user or installation manual. Use the proper manual section corresponding to the winter control system used on the condenser (VFD/Fan Speed Control or Liebert Lee-Temp Control) and the refrigerant to be charged into the system.

---

## 4.0 CHECKLIST FOR COMPLETED INSTALLATION

---

### 4.1 Moving and Placing Equipment

- 1. Unpack and check received material
- 2. Proper clearance for service access has been maintained around the equipment
- 3. Equipment is level and mounting fasteners are tight

### 4.2 Electrical

- 1. Line voltage connected and matches equipment nameplate
- 2. Power line circuit breakers or fuses have proper ratings for equipment installed
- 3. Control wiring connections completed between indoor cooling unit and condenser
- 4. All internal and external high and low voltage wiring connections are tight
- 5. VFD condensers only—Check for Delta-Connected Power Supply and make any needed adjustments per **3.8.1 - VFD Control Condensers Only**
- 6. Monitoring wiring connections completed, when equipped, to indoor cooling unit or external monitoring panel
- 7. Confirm that unit is properly grounded to an earth ground
- 8. Control transformer setting matches incoming power
- 9. Electrical service conforms to national and local codes
- 10. Check fans for proper phase rotation. Blades should rotate clockwise when viewing the unit from the fan guard side.

### 4.3 Piping

- 1. Piping is completed to corresponding indoor cooling unit refrigeration circuit.
- 2. Piping leak-checked, evacuated and charged with specified refrigerant.
- 3. Additional refrigerant oil added, if required, per circuit.
- 4. Piping is properly sized, sloped and trapped for proper oil return.
- 5. Piping is routed to reduce potential of rub-through or chaffing.
- 6. Refrigerant lines are secured to condenser leg(s).

### 4.4 Other

- 1. Fans rotate freely and in proper direction
- 2. Adjust ambient thermostat setpoints to match setpoints on the electrical schematic supplied with the condenser.
- 3. Foreign material removed from in and around all equipment installed (construction materials, construction debris, etc.).
- 4. Installation materials and tools have been removed from in and around all equipment (literature, shipping materials, tools, etc.).
- 5. Blank start-up sheet located, ready for completion by installer or start-up technician.

---

## 5.0 OPERATION

---



### WARNING

Risk of electric shock. Can cause injury or death.

Disconnect all local and remote electric power supplies before working within. Unit contains potentially lethal electrical voltage.

Only properly trained and qualified personnel may perform repair, maintenance and cleaning operations.

The fans may start unexpectedly. Disconnect power supply before working on unit. Line side of factory disconnect remains energized when disconnect is off. Use a voltmeter to make sure power is turned off before checking any electrical connections or functions.

### 5.1 Startup Checklist

Refer to **4.0 - Checklist for Completed Installation** and verify that all installation items have been completed before beginning to start the condenser.

### 5.2 Startup

- Locate “Liebert Condensers and Drycoolers Warranty Inspection Check Sheet” (Document # SAFM-8542-54).
- Turn the condenser disconnect ON. Indoor units should be turned on and set for cooling to allow operation of condenser.
- Check the fans for proper rotation: Clockwise when viewing the unit from the fan guard (top) side. Check that air is being drawn through the coil and discharged out the fan assembly. Some ambient thermostats may need to be temporarily adjusted to lower temperature settings to observe all fans operate. Readjust thermostat settings to correspond to setpoints shown on the electrical schematic supplied with the unit.
- Complete “Liebert Condensers and Drycoolers Warranty Inspection Check Sheet” (Document # SAFM-8542-54).



### NOTE

*This document must be completed and forwarded to your local Emerson sales office to validate warranty.*

- Contact your local Emerson sales representative or Liebert Precision Cooling support if you have any questions or problems during unit startup and commissioning.
- Local Emerson sales offices and Liebert Precision Cooling support contacts can be found at [www.liebert.com/servicesupport\\_pages/ServiceSupport.aspx?x=servicesupport](http://www.liebert.com/servicesupport_pages/ServiceSupport.aspx?x=servicesupport) or by calling 1-800-LIEBERT.

---

## 6.0 SYSTEM MAINTENANCE

---



### WARNING

Risk of electric shock. Can cause injury or death.

Disconnect all local and remote electric power supplies before working in the unit. Use voltmeter to make sure power is turned Off before making any electrical connections.

Unit contains lethal voltage in some circuits.

Only properly trained and qualified personnel may perform repair, maintenance and cleaning operations.

The fans may start unexpectedly. Disconnect power supply before working on unit. Line side of factory disconnect remains energized when disconnect is off. Use a voltmeter to make sure power is turned off before checking any electrical connections or functions.

### 6.1 General Procedures



#### NOTE

*When ordering replacement parts for equipment, it is necessary to specify unit model number, serial number, and voltage. Please record those numbers in the spaces below.*

- *Model Number* \_\_\_\_\_
- *Serial Number* \_\_\_\_\_
- *Voltage/Phase/Frequency* \_\_\_\_\_

Periodic attention is necessary for continued satisfactory operation of your unit. Restricted air flow through the condenser coil, reduced airflow from non-functioning fans and low refrigerant system charge levels will reduce the operating efficiency of the unit and can result in high condensing temperatures and loss of cooling. In winter, do not permit snow to accumulate around the sides or underneath the condenser coil.

Monthly and semi-annual inspections and maintenance are recommended for proper system operation. Use copies of **6.2.2 - Maintenance Inspection Checklist** for each of these inspections.

If performance or operation problems are detected at anytime, refer to **Table 14 - Troubleshooting** for required action.

## **6.2 Special Procedures**

### **6.2.1 Condenser Cleaning**

Keeping the outdoor condenser coils clean is an important factor in maintaining peak efficiency, reliability and long life of the equipment. It is much easier to keep up on frequent cleanings rather than wait until heavy build up has occurred which may create head pressure problems with the evaporator units.

#### **When to Clean**

Normal conditions typically dictate cleaning twice a year, spring and fall. On-site or area conditions such as cottonwood trees, construction, etc., can increase cleaning frequency. On your standard monthly preventive maintenance schedule, a visual inspection of the coil is recommended to monitor conditions.

#### **What to Use**

The best overall condenser coil cleaner to use is plain water. If the coil has been maintained and cleaned at regular intervals, water is sufficient to remove dirt and debris from the fins. Heavy build up on the exterior of the fins can be removed with a brush. Water pressure from a garden hose and sprayer usually works well. If a pressure washer is used, make sure the equipment is set to a lower pressure setting and that the nozzle is set to the fan spray, not stream. Otherwise, damage to the fins could result. If a cleaner is required, we recommend a non-acidic type cleaner be used. Acid-type cleaners can be aggressive to the coil fins as well as surrounding areas. Many sites do not allow the use of acidic cleaners for environmental reasons.

#### **How to Clean**

The absolute best way to clean coils is from the inside out. This requires disconnecting the power supply from the condenser before working on the unit. The fan guards and fan blades must be removed to gain access to the coil surface. The sprayer can then be worked across the coil using the water/cleaning solution, pushing the dirt and debris out the bottom of the coil. Although this does extend the time involved, the results are well worth it. This method should be used at least once a year. Spraying the coil from the outside repeatedly can push a majority of the dirt to the inner section of the fins and continue to restrict air flow. Keep in mind you may not have the luxury of shutting the unit(s) down for an extended time. A pre-scheduled shutdown with the operator may be in order. If you are using a cleaner along with the spraying process, follow recommended manufacturer instructions and be sure to rinse the coil thoroughly. Any residue left on the coil can act as a magnet to dirt.

Reinstall and secure the fan blades and fan guards after the cleaning is finished. Last, reconnect the power supply to the condenser.

**6.2.2 Maintenance Inspection Checklist**

Date: \_\_\_\_\_

Prepared By: \_\_\_\_\_

Model #: \_\_\_\_\_

Serial Number: \_\_\_\_\_



**NOTE**

*Regular inspections are necessary to ensure that the cooling fins are clean. Should inspection reveal dirt or corrosion, appropriate cleaning should be performed.*

Monthly	Semiannually
<p><b>Condenser</b></p> <ul style="list-style-type: none"> <li>___ 1. Coil surfaces free of debris</li> <li>___ 2. Fans free of debris</li> <li>___ 3. Fan motors securely mounted</li> <li>___ 4. Motor bearings in good condition</li> <li>___ 5. Check all refrigerant lines and capillaries for vibration isolation. Support as necessary.</li> <li>___ 6. No refrigerant leaks.</li> </ul> <p><b>Condenser Electrical Panel</b></p> <ul style="list-style-type: none"> <li>___ 1. On VFD condenser models, check SPD protection status indicator light.</li> </ul>	<p><b>Condenser</b></p> <ul style="list-style-type: none"> <li>___ 1. Complete all monthly items</li> <li>___ 2. Piping in good condition</li> <li>___ 3. Inspect refrigerant lines for signs of oil leaks. Repair leaks as found.</li> <li>___ 4. Check refrigerant charge level in each receiver tank (if equipped), based on procedures in the indoor unit's manual. Continuous system operation required.</li> <li>___ 5. Wash coil as needed</li> <li>___ 6. Repair bent or damaged fins.</li> </ul> <p><b>Condenser Electric Panel</b></p> <ul style="list-style-type: none"> <li>___ 1. Check all electrical connections</li> <li>___ 2. Check contactors for pitting</li> <li>___ 3. Operational sequence/setpoints</li> </ul> <p><b>Fan Motors</b></p> <ul style="list-style-type: none"> <li>___ 1. Motor #1 amp draw _____ amps</li> <li>___ 2. Motor #2 amp draw _____ amps</li> <li>___ 3. Motor #3 amp draw _____ amps</li> <li>___ 4. Motor #4 amp draw _____ amps</li> <li>___ 5. Motor #5 amp draw _____ amps</li> <li>___ 6. Motor #6 amp draw _____ amps</li> <li>___ 7. Motor #7 amp draw _____ amps</li> <li>___ 8. Motor #8 amp draw _____ amps</li> </ul>

**Notes**

---



---



---



---



---



---



---



---

**Signature:** \_\_\_\_\_

Make photocopies of this form for your records

Table 14 Troubleshooting

Symptom	Possible Cause	Check or Remedy
Condenser will not start	No power to condenser	Check voltage at input terminal block
	Circuit breaker for low voltage transformer in condenser is tripped	Locate problem in condenser electrical panel and repair
	No low voltage signal to/from indoor unit	Locate open circuit and repair
Low indoor unit suction pressure	Insufficient refrigerant in system	Check for leaks, repair, and add refrigerant
	Fan-cycling ambient thermostats setpoints too low	Check schematic for recommended setpoints and adjust.
Low discharge pressure	Faulty head pressure control valve or condenser FSC/VFD control	Replace if defective
High discharge pressure	Dirty condenser fins	Clean coil
	Condenser fans not operating	Check for low voltage signal from indoor unit
		Check fan motors and fuses
		Check for correct ambient thermostat setpoints, as applicable.
High refrigerant charge	Check refrigerant charge	
VFD Condenser trips out on overvoltage (OU displayed on VFD controller)	Supply voltage is Delta configuration or is ungrounded/high impedance	Shut off AC voltage, locate the VFD, pull out the EMC tab and reconnect power
SPD indicator lights are extinguished or red LED is illuminated and monitoring terminals 11/12 are closed	No voltage or improper phasing exists at condenser	Check voltage at input terminal block
	Electrical connections to SPD are faulty	Locate connection problem and repair
	A surge exceeding the rating of the SPD has occurred	Replace SPD and inspect other components for damage and replace them if necessary

# Ensuring The High Availability Of Mission-Critical Data And Applications.

Emerson Network Power, a business of Emerson (NYSE:EMR), is the global leader in enabling *Business-Critical Continuity™* from grid to chip for telecommunication networks, data centers, health care and industrial facilities. Emerson Network Power provides innovative solutions and expertise in areas including AC and DC power and precision cooling systems, embedded computing and power, integrated racks and enclosures, power switching and controls, infrastructure management, and connectivity. All solutions are supported globally by local Emerson Network Power service technicians. Liebert AC power, precision cooling and monitoring products and services from Emerson Network Power deliver Efficiency Without Compromise™ by helping customers optimize their data center infrastructure to reduce costs and deliver high availability.

While every precaution has been taken to ensure the accuracy and completeness of this literature, Liebert Corporation assumes no responsibility and disclaims all liability for damages resulting from use of this information or for any errors or omissions.

© 2008 Liebert Corporation

All rights reserved throughout the world. Specifications subject to change without notice.

® Liebert is a registered trademark of Liebert Corporation.

All names referred to are trademarks or registered trademarks of their respective owners.

SL-10066\_REV3\_10-10

## Technical Support / Service

### Web Site

[www.liebert.com](http://www.liebert.com)

### Monitoring

[liebert.monitoring@emerson.com](mailto:liebert.monitoring@emerson.com)

800-222-5877

Outside North America: +00800 1155 4499

### Single-Phase UPS & Server Cabinets

[liebert.upstech@emerson.com](mailto:liebert.upstech@emerson.com)

800-222-5877

Outside North America: +00800 1155 4499

### Three-Phase UPS & Power Systems

800-543-2378

Outside North America: 614-841-6598

### Environmental Systems

800-543-2778

Outside the United States: 614-888-0246

### Locations

#### United States

1050 Dearborn Drive

P.O. Box 29186

Columbus, OH 43229

#### Europe

Via Leonardo Da Vinci 8

Zona Industriale Tognana

35028 Piove Di Sacco (PD) Italy

+39 049 9719 111

Fax: +39 049 5841 257

#### Asia

29/F, The Orient Square Building

F. Ortigas Jr. Road, Ortigas Center

Pasig City 1605

Philippines

+63 2 687 6615

Fax: +63 2 730 9572

## Emerson Network Power.

The global leader in enabling *Business-Critical Continuity™*

■ AC Power

■ Embedded Computing

■ Outside Plant

**EmersonNetworkPower.com**

■ Racks & Integrated Cabinets

■ Connectivity

■ Embedded Power

■ Power Switching & Controls

■ Services

■ DC Power

■ Infrastructure Management & Monitoring

■ **Precision Cooling**

■ Surge Protection